



1455 Westec Dr. ♦ P. O. Box 25755 ♦ Eugene, Oregon 97402
Website: www.internationaldoor.com ♦ e-mail: info@internationaldoor.com

Instructions to Mull Door & Sidelights Together

Before you install the Door System, all parts must be weatherized. Unscrew and remove the sweeps, and remove the weatherstripping from the kerfs of the jambs and astragal. Please refer to our Finishing Recommendations in the IDL Care and Maintenance Brochure.

1. Remove Door from frame and remove the weatherstripping.
2. Lay frame down with the outside facing up.
3. Lay sidelight(s) down next to frame with outside facing up. Be sure the configuration is correct.
4. If applicable, slide on sill extender.
5. Flush the edges of the frames and clamp together – being careful to protect surfaces.
6. Drill holes through the frame into the sidelight, placing holes where the weatherstrip will cover. Use a $\frac{7}{64}$ " drill bit in at least six places evenly spaced along each jamb.
7. Using the holes drilled through the frame, screw the door frame to each sidelight frame using 1 $\frac{1}{4}$ " drywall screws.
8. For a more durable assembly you can use an exterior grade wood glue between the jamb sides before screwing together.
9. You can staple the door and sidelight joints – front and back – as the mull caps will cover these seams.
10. Install the unit in opening.
11. Reinstall door into frame and reinstall weatherstripping.
12. Trim with appropriate mull cap covers, brickmold and casing if applicable.